

Our Business is to provide you with the right tool for the job.

Set-up is everything...
Let Western's professional team help you spec the pump, hose, and accessory combination to get the most of your equipment's productivity potential.



Fireproofing

Standard Set-up

3 3/4" Cylinders,
3" Manifold Output,
8" Stroke,
and Manifold Compression-Kit.

Plastering

Standard Set-up

3 1/2" Cylinders,
2" Manifold Outlet,
6" Stroke,
and 1/2" screen on mixer or Hopper.



Shown with POWERDUMP mixer



Pool Plastering & Pebble Finish